


Entertainment Connector End Views


Amplifier Connector C1



73156

Connector Part Information		<ul style="list-style-type: none"> • 12110088 • 24-Way F Micro-Pack 100 Series (LT GRY) 	
Pin	Wire Color	Circuit No.	Function
A1	DK GRN	145	Power Antenna Relay Feed - Coil
A2	BRN/WHT	367	Remote Radio Signal - Left Audio (Envoy Only)
A3	BLK/WHT	372	Remote Radio Signal - Left Audio (Envoy Only)
A4	DK GRN/WHT	368	Remote Radio Signal - Right Audio (Envoy Only)
A5	YEL	116	Speaker Return - Left Rear
A6	BRN	199	Speaker Feed - Left Rear
A7	PPL	1952	Power Door Relay Feed - Lock Coil 2
A8	LT GRN	1852	Speaker Feed - Right Front - Tweeter
A9	DK BLU	46	Ignition Switch Output - Accessory 6
A10	LT BLU	115	Speaker Return - Right Rear
A11	YEL	1956	Speaker Return - Left Front - Tweeter


Amplifier Connector C1 (cont'd)



73156

Connector Part Information		<ul style="list-style-type: none"> • 12110088 • 24-Way F Micro-Pack 100 Series (LT GRY) 	
Pin	Wire Color	Circuit No.	Function
A12	BLK	1856	—
B1	BARE	2011	Drain Wire Return - Left Front Audio
B2	BARE	2012	Drain Wire Return - Left Front Audio
B3	BARE	514	Drain Wire Return - (Envoy Only)
B4	PNK	314	Radio Signal On - (Envoy Only)
B5	TAN	511	Audio Signal - Left Front - Low Level
B6	LT GRN	512	Audio Signal - Right Front - Low Level
B7	BRN	599	Audio Signal - Left Rear - Low Level
B8	DK BLU	546	Audio Signal - Right Rear - Low Level
B9	ORN/BLK	1546	Audio Return - Front - Low Level
B10	DK GRN/WHT	1547	Audio Return - Rear - Low Level
B11-B12	—	—	Not Used

Amplifier Connector C2




73158

Connector Part Information

- 12110626
- 8-Way F Metri-Pack 280 Series, Flex Lock (GRY)

Pin	Wire Color	Circuit No.	Function
A	BLK	1050	Ground
B	—	—	Not Used
C	TAN	201	Speaker Feed - Left Front
D	LT GRN	200	Speaker Feed - Right Front
E	DK GRN	117	Speaker Return - Right Front
F	GRY	118	Speaker Return - Left Front
G	—	—	Not Used
H	ORN	1340	Fuse Output Battery

Door Speaker, LH




280768

Connector Part Information

- 12052832
- 2-Way F Metri-Pack 150 Series (BLK)

Pin	Wire Color	Circuit No.	Function
A	YEL	116	Speaker Return - Left Rear
B	BRN	199	Speaker Feed - Left Rear

Door Speaker, RH




280768

Connector Part Information

- 12052832
- 2-Way F Metri-Pack 150 Series (BLK)

Pin	Wire Color	Circuit No.	Function
A	LT BLU	115	Speaker Return - Right Rear
B	DK BLU	46	Speaker Feed - Right Rear

Door Speaker, LH Rear (4-Door Utility)




95782

Connector Part Information

- 12052833
- 2-Way M Metri-Pack 150 Series (BLK)

Pin	Wire Color	Circuit No.	Function
A	YEL	116	Speaker Return - Left Rear
B	BRN	199	Speaker Feed - Left Rear

Door Speaker, RH Rear (4-Door Utility)




95782

Connector Part Information

- 12052833
- 2-Way M Metri-Pack 150 Series (BLK)

Pin	Wire Color	Circuit No.	Function
A	YEL	116	Speaker Return - Right Rear
B	BRN	199	Speaker Feed - Right Rear

IP Speaker, LH (Uplevel)




258301

Connector Part Information

- 12064778
- 2-Way M Metri-Pack 150 Series (GRN)

Pin	Wire Color	Circuit No.	Function
A	YEL	118	Speaker Return - Left Front
B	BLK	201	Speaker Feed - Left Front

IP Speaker, LH (Base)




280768

Connector Part Information

- 12052832
- 2-Way F Metri-Pack 150 Series (BLK)

Pin	Wire Color	Circuit No.	Function
A	GRY	118	Speaker Return - Left Front
B	TAN	201	Speaker Feed - Left Front

IP Speaker, RH (Base)




280768

Connector Part Information

- 12052832
- 2-Way F Metri-Pack 150 Series (BLK)

Pin	Wire Color	Circuit No.	Function
A	DK GRN	117	Speaker Return - Right Front
B	LT GRN	200	Speaker Feed - Right Front


IP Speaker, RH (Uplevel)



258301

Connector Part Information		<ul style="list-style-type: none"> • 12064778 • 2-Way M Metri-Pack 150 Series (GRN) 	
Pin	Wire Color	Circuit No.	Function
A	PPL	117	Speaker Return - Right Front
B	LT GRN	200	Speaker Feed - Right Front


Radio (All Except Bravada) Connector C1



62435

Connector Part Information		<ul style="list-style-type: none"> • 12047531 • 10-Way F Micro-Pack 100 Series (BLK) 	
Pin	Wire Color	Circuit No.	Function
1	GRY	118	Audio Signal - Left Front (w/o Amp)
1	TAN	511	Audio Signal - Left Front (w/ Amp)
2	TAN	201	Audio Signal Left - Front (w/o Amp)
2	ORN/BLK	1546	Audio Return - Front (w/ Amp)
3	DK GRN	117	Audio Signal - Right Front (w/o Amp)
3	LT GRN	512	Audio Signal - Right Front (w/ Amp)
4	LT GRN	200	Audio Signal Right - Front (w/o Amp)
4	BARE	1573	Drain Wire Return - Front Audio (w/ Amp)
5	BLK	1050	Ground
6	PPL/WHT	1382	LED Dimming Signal
7	GRY	1220	Fuse Output - Instrument Panel Lamps
8	—	—	Not Used (w/o Amp)
8	DK GRN	145	Switched Power Output - Amp Feed (w/ Amp)
9	DK GRN	1301	Fuse Output - Retained Accessory Power
10	ORN	340	Fuse Output - Battery - Type III Fuse


Radio (All Except Bravada) Connector C2



62477

Connector Part Information		<ul style="list-style-type: none"> • 12065785 • 10-Way F Micro-Pack 100 Series (GRY) 	
Pin	Wire Color	Circuit No.	Function
11	—	—	Not Used
12	PNK	314	Radio Signal - On (Envoy Only)
13	LT GRN	1011	Remote Radio Control Signal (Envoy Only)
14	—	—	Not Used (Pick-up)
14	DK BLU	1796	Radio Control Signal - Steering Column (Utility)
15	DK GRN	835	Diagnostic Signal - Entertainment and Comfort (Envoy Only)
16	DK GRN	389	Vehicle Speed Signal - 4000 Pulses Per Mile
17	LT BLU	115	Speaker Return - Right Rear (w/o Amp)
17	DK BLU	546	Audio Signal - Right Rear (w/ Amp)
18	DK BLU	46	Audio Signal Right - Rear - Low Level (w/o Amp)
18	DK GRN/ WHT	1547	Audio Return - Rear - Low Level (w/ Amp)
19	YEL	116	Speaker Return - Left Rear (w/o Amp)
19	BRN	599	Audio Signal - Left Rear - Low Level (w/ Amp)
20	BRN	199	Audio Signal - Left Rear (w/o Amp)
20	BARE	1574	Drain Wire Return - Rear Audio (w/ Amp)

Radio (All Except Bravada) Connector C3 (w/ Remote Audio Player)




62467

Connector Part Information		<ul style="list-style-type: none"> • 12064980 • 9-Way F Micro-Pack 100 Series (BLK) 7 	
Pin	Wire Color	Circuit No.	Function
7	LT BLU	1405	Tape Player Signal - Remote - Audio Communication
8	GRY	1220	Dimming Signal (except Envoy)
9	BARE	701	Drain Wire Return
10	DK GRN/ WHT	368	Remote Radio Signal - Right Audio
11	BRN/ WHT	367	Remote Radio Signal - Left Audio
12	BLK/ WHT	372	Remote Radio Return - Audio
13	BLK	1050	Ground
14	DK GRN	835	Diagnostic Signal - Entertainment and Comfort
15	ORN	340	Fuse Output - Battery

↑
Pin 7 or 14; Signal
to Radio Control that
Aux is in use?

Pin 15: RAP RDO PWR


Radio w/ ATC CD (Bravada)



73222

Connector Part Information		<ul style="list-style-type: none"> • 12110115 • 32-Way F Micro-Pack 100 Series (BLU) 	
Pin	Wire Color	Circuit No.	Function
E1-E11	—	—	Not Used
E12	BRN	199	Speaker Feed - Left Rear
E13	YEL	116	Speaker Return - Left Rear
E14	DK GRN	117	Speaker Feed - Right Front
E15	LT GRN	200	Speaker Feed - Right Front
E16	BLK	1050	Ground
F1	ORN	340	Fuse Output - Battery - Type II Fuse
F2	DK GRN	1301	Fuse Output - Retained Accessory
F4	GRY	1220	Fuse Output - Instrument Panel Lamps - Type III Fuse
F5	PPL/WHT	1382	Led Dimming Signal
F6-F11	—	—	Not Used
F12	TAN	201	Speaker Feed - Left Front
F13	GRY	118	Speaker Return - Left Front
F14	LT BLU	115	Speaker Return - Right Rear
F15	DK BLU	46	Speaker Feed - Right Rear
F16	—	—	Not Used


Rear Seat Audio Control (Envoy Only)



73151

Connector Part Information		<ul style="list-style-type: none"> • 12064799 • 12-Way F Micro-Pack 100 Series (BLK) 	
Pin	Wire Color	Circuit No.	Function
A	DK GRN	1301	Fuse Output - Retained Accessory Power
B	BRN	2409	Fuse Output - Retained Accessory Power
C	BLK	1050	Ground
D	PNK	314	Radio Signal - On
E-H	—	—	Not Used
J	DK GRN/WHT	368	Remote Radio Signal - Right Audio
K	BLK/WHT	372	Remote Radio Return - Audio
L	BRN/WHT	367	Remote Radio Signal - Left Audio
M	LT GRN	1011	Remote Radio Control Signal


Remote Audio Player



62467

Connector Part Information		<ul style="list-style-type: none"> • 12064980 • 9-Way F Micro-Pack 100 Series (BLK) 	
Pin	Wire Color	Circuit No.	Function
7	LT BLU	1405	Tape Player Signal - Remote - Audio Communication
8	GRY	1220	Fuse Output - Instrument Panel Lamps - Type III
8	—	—	Not Used (Envoy Only)
9	BARE	514	Drain Wire Return
10	DK GRN/ WHT	368	Remote Radio Signal - Right Audio
11	BRN/WHT	367	Remote Radio Signal - Left Audio
12	BLK/WHT	372	Remote Radio Return - Audio
13	BLK	1050	Ground
14	DK GRN	835	Diag Signal - Entertainment and Comfort
15	ORN	340	Fuse Output - Battery - Type III Fuse


Speaker, LH Rear (2-Door Utility)



280768

Connector Part Information		<ul style="list-style-type: none"> • 12052832 • 2-Way F Metri-Pack 150 Series (BLK) 	
Pin	Wire Color	Circuit No.	Function
A	YEL	116	Speaker Return - Left Rear
B	BRN	199	Speaker Feed - Left Rear

Speaker, RH Rear (2-Door Utility)



280768

Connector Part Information		<ul style="list-style-type: none"> • 12052832 • 2-Way F Metri-Pack 150 Series (BLK) 	
Pin	Wire Color	Circuit No.	Function
A	LT BLU	115	Speaker Return - Right Rear
B	DK BLU	46	Speaker Feed - Right Rear